

MILLIMETER-WAVE 5G BEAMFORMING AND PHASED ARRAY BASICS



Anokiwave
mmW Solutions. Enabling a new world


 www.anokiwave.com
 innovation@anokiwave.com

Table of Contents

- 5G is Here..Are you Ready 3
- Active Antenna Basics 4
- Beamforming Principles and Considerations..... 5
- Array Directivity and Gain 6
- Active Antenna Beamforming Considerations 15
- Analog Beamforming..... 15
- Digital Beamforming 16
- Hybrid Beamforming..... 18
- Unique Beamforming Features..... 20
- Conclusion 21

“5G is happening - quickly. 2018 was the year of the first true 5G trials and deployments in dozens of cities worldwide. mmW fixed wireless will be the critical first consumer application for 5G, and its rollout will be similar to Wi-Fi – viral and quickly becoming ubiquitous. We will see a radical use case evolution with an explosion of innovation and a tipping point in mmW Active Antenna cost improvements that will enable 5G everywhere.”

5G is Here..Are you Ready

by David Corman, Anokiwave, Inc.

Experts and major industry bodies have spoken — 5G will arrive faster than many envisioned, and our industry is in the middle of an age of innovation that has not been seen for 25 years. Companies developing systems for millimeter-wave (mmWave) 5G networks are in front of regulating bodies, working to anticipate where the market will move and how to meet the needs of their customers. One thing is certain — active antenna beamforming at mmWave bands is an essential technology required to realize the revolutionary new features and capabilities promised by 5G.

This article discusses the basic active antenna beamforming concepts that form the heart of the mmWave 5G system, as well as the general beamforming architectures used in active antennas.



Active Antenna Basics

An active antenna, also known as a phased array antenna; is defined by the Phased Array Antenna Handbook¹ as consisting “of multiple stationary elements, which are fed coherently and use variable phase or time delay control at each element to scan a beam to given angles in space.” Thus, active antennas have electronically-steered beams with no moving parts; steering occurs within the ICs placed at the radiating elements in the antenna.

Active antennas with beamforming ICs have what is referred to as a “soft failure mechanism,” meaning that, because there are many elements in an array, the failure of a few elements typically has little effect on the performance of the antenna as a whole. Active antennas can steer beams in microseconds, as well as support multiple, simultaneous, independently-steerable beams. With no mechanically gimbaled parts, they are low-profile and reliable. Active antennas are able to steer nulls and, since they have many elements, they have high degrees of freedom to block interferers and jammers. Active antennas are capable of generating precise, radiating aperture patterns.

For 5G communications, the antennas will operate at mmWave frequencies such as 24 GHz, 26 GHz, 28 GHz, 37 GHz, and 39 GHz. At these high frequencies, the wavelengths are very short, allowing many antenna elements to be placed in a compact, highly directive aperture, which offsets the high path loss at mmWave frequencies. Another key benefit of the highly directive beams is that they provide spatial diversity, where multiple beams can reuse the same frequency spectrum, greatly increasing system capacity.

To make it practical and efficient for 5G, Anokiwave has applied the essential technology of active antennas to a line of Silicon Core ICs covering the different millimeter-wave bands of 5G wireless networks with the performance required to create low-cost 5G wireless links.

Beamforming Principles and Considerations

The analysis of beamforming by an active antenna is basically an exercise in complex arithmetic. As shown in Fig. 1, we have a linear array along the x-axis, with the antenna elements spaced by d , which is equal to a free-space wavelength divided by two. If each element is energized by the appropriate phase, then a beam can be formed coherently in the far field at the desired direction.




Figure 1: Analysis of Active Antenna Beamforming

In Fig. 2, we take an example of an aircraft target that is not in the boresight direction of the array, such that the range from the aircraft to each element in the array is slightly different. The fact that the elements are spaced at d apart, and the angle of arrival of energy from the aircraft is θ , then the incremental path length difference between adjacent elements is $d \cdot \cos(\theta)$. To compensate for this difference in path length, we can place phase shifters behind each element. When the appropriate phase shift is applied, we can coherently form a beam in the far field. Remember that, to form a beam, energy must arrive at the summation node at the same phase, at the same amplitude, and at the same time. We call this “coherent combining.”




Figure 2: Coherent Summation of Energy - Linear Array

Array Directivity and Gain

Directivity is the measure of how concentrated the antenna gain is in a given direction relative to an isotropic radiator. It follows a $10 \cdot \log(N)$ relationship, where N is the number of elements in the array. Gain, however, takes into account directivity as well as ohmic and scan losses.

So, in general, array gain equals $10 \cdot \log(N)$, plus the embedded element gain (G_e), minus the ohmic and scan losses:

$$\text{Array gain} = 10 \cdot \log(N) + G_e - L_{\text{OHMIC}} - L_{\text{SCAN}}$$

G_e is the embedded element gain, which is the gain of a single radiator embedded in the array. If the radiating elements are spaced $\lambda/2$ apart in both the azimuth and elevation directions, then the area of each element is $\lambda^2/4$. Since antenna gain is $4\pi/\lambda^2 \cdot A_e$, where A_e is the effective area of the antenna, then the G_e equals π or 5 dBi.

Note that for every element added to an array, the G/T of a receiver (Rx) array increases by $10 \cdot \log(N)$. You are increasing aperture size, but the noise figure stays constant. In contrast, the equivalent isotropically radiated power (EIRP) of the transmitter (Tx) array increases by $20 \cdot \log(N)$, since for every element you add, you add array gain and transmit power in the far field. It is clear, then, that G/T is much more challenging to achieve with an active antenna than EIRP.

Fig. 3A shows how G/T varies with array size. In this plot, the assumed lattice spacing is $\lambda/2$, the system noise figure is 5 dB, and 0.5 dB of loss has been included for both feed loss and radome loss. Fig. 3B shows how EIRP varies with antenna size and RF power/element. In this graph, the same $\lambda/2$ lattice spacing is used, and +9 dBm transmit power per element is assumed.




Figure 3A: Example G/T vs. Number of Elements




Figure 3B: Example EIRP vs. Number of Elements

System engineers typically generate detailed G/T and EIRP budgets that consider a wide range of variables, including system noise figure, embedded element gain, frequency of operation, transmit power per element, loss between the element and the T/R functions, scan loss, the effect of polarizers and radomes, and temperature.

Fig. 4 shows some examples of linear arrays — specifically 16, 32, and 64 elements. The graph shows main lobes and side lobes. The antenna directivity follows $10 \cdot \log(N)$, as we've established previously, where N is the number of elements in the array. Every time we double the size of the antenna, the beam width halves. And, every time we double the size of the antenna, the directivity doubles, or increases by 3 dBi.




Figure 4: Examples of Uniformly Illuminated Linear Arrays: 64, 32, 16 Elements

One characteristic of using phase shifters to steer active antenna beams is called beam squint (Fig. 5). Phase shifters electrically steer a beam by approximating time delay. The result is that they only steer the beam perfectly at the center frequency; they understeer at the maximum operating frequency, and they oversteer at the minimum operating frequency. Yet, phase shifters are preferred over time delay functions because of the trade-off between accuracy and circuit size. In fact, phase shifters provide good accuracy for almost all active antenna applications, with the exceptions being very wide instantaneous bandwidth applications, such as EW, or very large arrays.




Figure 5: Beam Squint

Another characteristic of all active antennas is the loss of aperture gain as the beam is steered away from the boresight direction — defined as $\theta=0$. This characteristic, called scan loss, follows $10 \cdot \log(\cos^N(\theta))$ power, where θ is the scan angle off boresight and N is a numeric value, typically in the 1.3 range, which accounts for the non-ideal isotropic behavior of the embedded element gain.

Fig. 6 plots scan loss in dB vs. scan angle, measured in degrees. Note, at the origin, where the boresight angle is zero, there is no scan loss. As the scan angle is increased to 45 degrees, there is 2 dB scan loss. If scan angle is increased to a practical limit of 60 degrees, there is 4 dB scan loss. Active antennas must therefore be oversized to provide the required G/T and EIRP under maximum scan conditions.





Figure 6: Scan Loss

Tapering is the process of assigning different gains to the various elements within the array, where the center elements are assigned the highest gains, and the outer elements are assigned lower gains. Fig. 7 illustrates how various levels of taper can be achieved. The example shown is a 64-element array, so that the maximum gain of each curve occurs at element 32, which is the center of the array. Note that, the more quickly element gain is reduced as the elements get farther from the center of the array, the greater the suppression of side lobes. The graph in Fig. 7 shows us the effect of side lobe levels of -20, -30, -40, and -50 dB.



Low Sidelobe Distributions “Taper” to Aperture:
-20 dB, -30 dB, -40 dB, -50 dB relative to peak

Figure 7: Tapering vs. Side Lobe Level

This is why beam forming typically includes amplitude control per element, not just phase control. If all elements are treated with the same gain, it is called “uniform illumination.” Uniform illumination results in -13 dBc first side lobe levels, which may be unacceptable for some applications due to regulatory, interference, or stealth reasons.

Gain control allows the system engineer to adjust the gain per element to achieve the desired lower side lobe levels.

Fig. 8 shows superimposed side lobe levels for various amounts of applied taper — specifically -20, -30, -40, and -50 dB, relative to the peak. Observe the side lobe level suppression, caused by the applied taper. This is a 64-element array with a directivity of 18 dBi ($10 \cdot \log(64)$).




Figure 8: Sample Taylor Distributions: -20 dB, -30 dB, -40 dB, -50 dB Relative to Peak

Anokiwave ICs typically provide gain controls at the element in the 0–31.5 dB range, in 0.5 dB steps, which is generally sufficient to provide for amplitude taper and other host system control needs. A final note is that taper does not change with scan angle.

Taper can be a good thing, but it does come at a price. When taper is applied, the directivity is less than uniform illumination for the same size array, and the beam widths are broader. Table 1 shows a range of different tapers applied to the array. The top row is the uniform illumination with -13 dBc side lobes, as previously described. Shown below are rows for -20, -30, -40, and -50 dB side lobe levels. Note that their directivity is decreasing, and the efficiency is decreasing. As shown in the table, if a -50 dB taper is applied, a full 2 dB efficiency is lost on the array.

Desired SLL dB (wrt peak)	B	D - Directivity (dBi)	η - Efficiency (dB)	$B_{\text{null-to-null}}$
-13.26	0	18.06	0.0	3.6
-20	0.7386	17.74	-0.32	4.5
-30	1.2762	17.05	-1.01	5.8
-40	1.7415	16.51	-1.55	7.2
-50	2.1793	16.08	-1.98	8.1

Table 1: Values of B for desired sidelobe levels in One Parameter Taylor Distributions

Another characteristic of active antennas is grating lobes, which are primarily affected by lattice spacing — the spacing between elements (variable d). To avoid parasitic grating lobes, which are antenna responses in undesired beam directions, the lattice spacing must follow these rules:

- $d/\lambda_0 < 1/(1+\sin\theta)$ for a rectangular lattice (Min. spacing = $0.5 \lambda_0$ at 90 deg scan)
- $d/\lambda_0 < 1.15/(1+\sin\theta)$ for a triangular lattice (Min. spacing = $0.575 \lambda_0$ at 90 deg scan)

Where λ_0 is the free space wavelength, θ is the max scan angle, and d is the spacing between antenna elements. A common value of lattice spacing for active antennas with rectangular lattices is $0.55 \lambda_0$.

Fig. 9 shows that required lattice spacing is a function of frequency. The graph plots lattice spacing in millimeters vs. frequency of operation. Note that, for lower frequencies, large lattice spacing makes planar active antennas not very challenging. But look what happens at 28 GHz and above: the lattice is rapidly contracting, which leaves very little room for the T/R functions and beam-forming electronics to fit with the lattice. Fitting within the lattice is critical to high-performance active antennas, as it guarantees minimum feed loss, which maximizes EIRP and minimizes receiver NF.





Figure 9: Lattice Spacing Example Calculation

$\lambda/2$ lattices at 5G mmWave bands are quite small: 5.4 mm at 28 GHz, and 3.85 mm at 39 GHz. This is where the high level of integration with silicon is critical. As mentioned above, the most efficient method to implement planar active antennas at mmWave is to fit the electronics within the lattice using highly integrated silicon ASICs, in the same plane as the radiating elements. As shown in Fig. 10 below, a four-element IC is optimal for signal routing and other component integration.

$\lambda/2$ lattices at 5G mmWave bands are small: 3.85 mm at 39 GHz. High level of integration is critical; the most efficient method to implement planar active antennas at mmWave is to fit the electronics within the lattice using highly integrated silicon ICs, in the same plane as the radiating elements. A quad IC is optimal for signal routing and other component integration.

Silicon = SWaP-C


Active Antenna Unit Cell Block Diagram



Features

- 4 radiating elements
- Dual polarization per element
- 5 bits phase steering (LSB= 11.25°)
- 5 bit amplitude, 31 dB DR

28 GHz unit cell (5.3 mm lattice)



39 GHz unit cell (3.85 mm lattice)



Highly integrated silicon quad core ICs are the only possible solution at mmW for low-cost, planar Active Antennas

Figure 10: Highly Integrated Silicon ICs are Critical to mmW Planar Active Antennas

Active Antenna Beamforming Considerations

Three general beamforming architectures are used in active antennas: analog beamforming, digital beamforming, and hybrid beamforming. In this section, we will describe each approach from a high level and then compare the pros and cons of each approach. Note that, in the sections below the block diagrams all denote receiver diagrams, but transmitter block diagrams look similar, just reversed in direction and using DACs instead of ADCs.

Analog Beamforming

All discussion thus far has addressed analog beamforming, where a phase shift is applied to each element in the array followed by coherent power summation. Included in the diagram (Fig. 11) is a suitable frequency downconverter and ADC to complete the system.




Figure 11: Analog Beamforming Block Diagram

Analog Beamforming Advantages	Disadvantages
Simplest hardware implementation	Single Beam
Hardware can fit within the lattice at high frequencies	Number of beams is fixed by hardware and cannot be changed
Beam benefits from the full array gain	
Lowest system DC power	

Table 2: Analog Beamforming Considerations

Digital Beamforming

In digital beamforming, the beams are formed using complex digital weights, rather than with analog phase shifters (Fig 12). To do this, a full receiver chain from antenna element to digits is required at every element in the array. This is practical only at low frequencies, such as S-band, where the lattices are large and there is plenty of room to place the required hardware on the array. This approach is not practical at mmWave frequencies, since inadequate real estate exists with the tight lattices.

Other significant challenges include high DC power consumption — especially if large bandwidths are to be digitized — signal routing complexity, where multiple bits of I and Q lines must be routed off the array to the digital processor (imagine routing 8 bits of I and 8 bits of Q times the number of elements in the array!), and LO signal routing within the array. On the plus side, if these challenges can be addressed, then this architecture is the most flexible, since multiple beams and nulls can be formed dynamically, with no change in hardware required, and each beam benefits from the gain of the full array.




Figure 12: Digital Beamforming Block Diagram

Digital Beamforming Advantages	Disadvantages
Extreme flexibility with number of beams and nulls	Highest DC Power
Can provide high number of beams	I/Q signal routing complexity
Number of beams can be changed dynamically with no change in hardware	LO signal routing complexity
Each beam benefits from the full array gain	Highest hardware complexity - full RF chain per element in the array
	Hardware cannot fit the lattice at high frequencies

Table 3: Digital Beamforming Considerations

Hybrid Beamforming

Hybrid beamforming is a cross between analog and digital beamforming. The beam concept (Fig. 13) involves the formation of analog (sub-array) beams from a portion of the full array. In Fig. 14, the wide black beam represents the embedded element's gain, the red beam is the analog sub array beam, and the two blue beams are the digital beams. Only two digital beams are shown for simplicity but, in fact, many beams can be formed.




Figure 13: Receive Hybrid Beamforming Block Diagram




Figure 12: Hybrid Beamforming Beam Illustration

The full array is broken into sub-arrays, with an individually steerable analog beam assigned to each sub-array. Then, digital beamforming is used to form many beams within the analog beams. The beauty of this approach is that it can be used at mmWave frequencies, it provides the digital flexibility to dynamically form many beams and nulls with no change in hardware, and it does not require a full RF chain per element, only a full RF chain per sub-array. With the many advantages that this approach offers, it is no wonder that this is the most popular beamforming approach used in emerging 5G communications systems today.

Hybrid Beamforming Advantages	Disadvantages
Extreme flexibility with number of beams and nulls	Digital beams can only be formed within the analog beams
Can provide high number of beams	
Number of beams can be changed dynamically with no change in hardware	
Hardware can fit within the lattice at high frequencies	
No complex signal routing	
No LOs to distribute in the array	

Table 4: Hybrid Beamforming Considerations


Unique Beamforming Features

Anokiwave offers the industry's broadest portfolio of mmW 5G ICs for all major bands and antenna configurations. We are enabling the commercialization of phased array/active antennas in all forms and use cases of 5G communications.

As the market leader in silicon ICs for mmWave 5G antennas, Anokiwave continues to execute on an aggressive strategy to deliver the technology needed for mmW 5G telecommunication networks with our second generation of 5G ICs supporting 3GPP compliance for 5G-NR now in volume production, and our platform of 3rd generation solutions recently announced.

Anokiwave's goal is to help customers build the most cost-effective arrays by improving the total cost of ownership for the service provider. Our 5G IC family offers savings in the active antenna cost structure with silicon-based ICs, the lowest cost monolithic processes in the world. Another important factor in reducing cost of the antenna is the elimination of array calibration using Anokiwave's ZERO-CAL® technology; removing array alignment and costly unnecessary factory testing while at the same time improving predictability of performance. While reducing the Active Antenna material costs is important, we also are able to improve the network operator's OPEX by minimizing energy consumption with Anokiwave's KINETIC-GREEN functionality. Using KINETIC-GREEN, our ICs have the ability to dynamically manage array DC power dissipation across multiple use case scenarios.


Looking to the future, we are focused in continuing to improve performance, to offer multiple variants in each IC generation, covering all 5G mmWave frequency bands, to meet the unique requirements of each use case within 5G, and most importantly to drive the cost down to what we call "ultra-low cost" ICs. With silicon-based ICs, we continue to innovate and lead the market in performance, digital functionality, cost reduction, and thermal management.



ZERO-CAL® ICs

Imagine a new world where array calibration is not needed... It's here.

Active Antenna Solutions for 5G Fast Beam Steering™



Conclusion

We have shown the key performance metrics for mmWave beamforming with active antennas.

To build and manufacture truly planar active antennas for 5G, all of the required beamforming and beam steering electronics must be integrated in the plane of the antenna and fit between the radiating elements. This becomes increasingly difficult at 5G mmWave frequencies due to the shrinking dimensions of the lattice, which is an inverse function of the wavelength. A single IC with all requisite beam forming functions for multiple elements is the most efficient way to achieve this functionality in a very small size.

Highly integrated silicon ICs, surface mounted at the antenna element, are the key to efficient arrays at the 5G mmWave frequencies. Emerging applications — especially next-generation SATCOM and 5G applications — need active antenna beamforming technology at commercial and consumer price points to be successful.

Highly integrated silicon ICs, surface mounted at the antenna element, are the key to efficient arrays at the 5G mmWave frequencies.

Emerging applications need active antenna beamforming technology at commercial and consumer price points to be successful.



www.anokiwave.com

Endnotes

1 **Phased Array Antenna Handbook, Second Edition by Robert J. Mailoux. Copyright 2005. ISBN: 9781580536899. Artech House.**