

**WEA101C****100 KHz – 200 MHz LOW NOISE WIDE BAND AMPLIFIER****REV A****February 2010**

Key Features



- 100 KHz ~ 200 MHz
- +/- 0.2 dB Gain Flatness
- 1.0 dB noise figure
- 30.0 dBm output IP₃
- 22.0 dB Gain
- 15.0 dBm P_{1dB}
- 1.35:1 VSWR
- Single Power Supply
- >68 Years MTBF
- RoHS compliant

Product Description

WEA101C integrates WanTcom proprietary low noise amplifier technology, high frequency micro electronic assembly techniques, and high reliability design to realize optimum low noise figure, wideband, high linearity, and unconditional stable performances together. With single +5.0V DC operation, the amplifier has optimal input and output matching in the specified frequency range at 50-Ohm impedance system. The amplifier has standard SMA connectorized WP-6 gold plated housing.

The amplifier is designed to meet the rugged standard of MIL-STD-202.

Applications

- Mobile Infrastructures
- LW & SW
- CATV/DBS
- Physics
- Security System
- Measurement
- Fixed Wireless



Specifications

Summary of the electrical specifications WEA101C at room temperature


Index	Testing Item	Symbol	Test Constraints	Min	Nom	Max	Unit
1	Gain	S ₂₁	100 KHz – 200 MHz	20	22		dB
2	Gain Variation	ΔG	100 KHz – 200 MHz		+/- 0.2	+/-0.5	dB
3	Input Return Loss	S ₁₁	100 KHz – 200 MHz	14	20		dB
4	Output Return Loss	S ₂₂	100 KHz – 200 MHz	14	20		dB
5	Reverse Isolation	S ₁₂	100 KHz – 200 MHz		25		dB
6	Noise figure	NF	10 MHz – 50 MHz		1.0	2.2	dB
			50 MHz – 200 MHz		0.8	1.2	
7	Output Power 1dB compression Point	P _{1dB}	100 KHz – 200 MHz	13	15		dBm
8	Output-Third-Order Interception point	IP ₃	Two-Tone, P _{out} +0 dBm each, 1 MHz separation	26	30		dBm
9	Current Consumption	I _{dd}	V _{dd} = +5 V		40		mA
10	Power Supply Voltage	V _{dd}	WEA101C	+4.7	+5	+5.3	V
			WEA101D	+7.0		+12	
11	Thermal Resistance	R _{th,c}	Junction to case			220	°C/W
12	Operating Temperature	T _o		-40		+85	°C
13	Maximum Average RF Input Power	P _{IN, MAX}	DC – 6 GHz			5	dBm

Absolute Maximum Ratings

Parameters	Units	Ratings
DC Power Supply Voltage	V	6.0 (+12V for WEA101D)
Drain Current	mA	50
Total Power Dissipation	mW	300
RF Input Power	dBm	5
Channel Temperature	°C	150
Storage Temperature	°C	-55 ~ 125
Operating Temperature	°C	-40 ~ 85
Thermal Resistance	°C/W	220

Operation of this device above any one of these parameters may cause permanent damage.

Functional Block Diagram







Ordering Information

Model Number	Feature
WEA101C	V _{dd} =+5.0V


Specifications and information are subject to change without notice.

**WEA101C****100 KHz – 200 MHz LOW NOISE WIDE BAND AMPLIFIER****REV A****February 2010**

WEA101D

 $V_{dd} = +7.0 \sim +12.0V$ **Typical Data****Outline, WP-6 Housing**

UNITS: INCH
[mm]
BODY: Brass
Finish: Gold Plating
RF Connector: SMA F Gold
 V_{dd} PWR: Feed through



Specifications and information are subject to change without notice.

WanTcom, Inc * Phone 01 952 746 6088 * FAX: 01 952 746 8818 * e-mail: sales@wantcominc.com * Web site: www.wantcominc.com



Application Notes:

A. SMA Torque Wrench Selection

Always use a torque wrench with 5 ~ 6 inch-lb coupling torque setting for mating the SMA cables to the amplifier. Never use torque more than 8 inch-lb wrench for tightening the mating cable to the connector. Otherwise, the permanent damage will occur to the SMA connectors of the amplifier. 8710-1582 (5 inch-lb) is one of the good torque wrench choice from Agilent Technology.

B. DC Power Line Connection

Strip the insulation layer at the end of DC power supply wire. The stripped distance should be in the range of 0.100" to 0.200". The 24 ~ 26 American Wire Gauge wire is suitable. Wound the stripped terminal wire about 1 to 2 turns on the DC feed thru center pin. Solder the wounded wire and the center pin together. Clean the soldering area by Q-tip with alcohol to remove the flux and residue.

Repeat the process to solder the DC return wire on the ground turret.

C. Mounting the Amplifier

Use three pieces of #4-40 with longer than 9/16" screws for mounting the amplifier on a metal-based chase. Flat and spring washers are needed to prevent the screw loosening during the shock and vibration. Always use the appropriate torque setting of the power screwdriver to mount them.
